



TRU-FRAME®
A name you can build on.

FRENCH DOOR INSTALLATION INSTRUCTIONS

1. Follow instructions provided with doors for the proper installation of both doors. Do not mount handles or air closer until completing step #4.

2. Trim astragal to center opening height less 1/4" for clearance and install on the inside of the stationary door with pan head screws provided. Pre-drill pilot holes with a 1/8" drill bit. (Illustration A)

3. Install slide-bolts at top and bottom of the stationary door as shown. (Illustration B) Be sure to allow for the doorstop clearance on the top slide-bolt. With the stationary door in the closed position, mark the locations for the header and threshold holes. Drill a 1/4" hole in the header and threshold at the marked locations to accept the slide-bolt.

4. Install the strike plate with the screws provided to the astragal on the stationary door as shown (Illustration C). Pre-drill pilot holes with a 1/8" drill bit. The strike is included in the hardware box. Use the strike shim provided if necessary. Be sure strike plate is set at a height that will not interfere with main door knob.

5. With the moving door in the closed position, place template provided in the hardware box against the edge of the astragal and follow instructions for drilling and mounting handle to moving door. Mount handle to stationary door and air closer to moving door if desired.

KIT INCLUDES:

- 1 - Astragal
- 8 - #8 x 3/4" Pan Head Screws
- 2 - Slide bolts w/screws
- 1 - Strike Plate and Shim

